




COOKTOP PARTS

For Models: RF264LXSQ2, RF264LXSB2
(Designer White) (Black)

30" ELECTRIC FREESTANDING
SELF CLEAN RANGE



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10162204	Owners Manual
	W10115599	Tech Sheet
	W10141166	Instructions, Installation
		Template, Anti-Tip
	9757142	English/Spanish
	9757143	English/French
	9762761	Safer Cooking Tips


Illus. No.	Part No.	DESCRIPTION
2		Bowl, Drip
	3196206	6" Gray
	3196207	8" Gray
	3196202	6" Black
	3196203	8" Black
	3195208	6" Chrome
	3195209	8" Chrome
3		Cooktop
	3186231	White
	3186233	Black

Illus. No.	Part No.	DESCRIPTION
4	3195060	Hinge, Cooktop (2)
5	3196178	Screw
6	308605	Strain Relief
7	3195812	Rod, Support (2)
8	814399	Receptacle, Elmnt
9	3196154	Screw
10		Element, Surface
	9761347	6" (2)
	9761345	8" (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RF264LXSQ2, RF264LXSB2
(Designer White) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	W10009080	Black Left Hand
	W10009090	Black Right Hand
	W10009040	White Left Hand
	W10009050	White Right Hand
2	9757609	Nameplate
3		Panel, Control
	9762083	Black
	9762081	White


Illus. No.	Part No.	DESCRIPTION
4		Switch, Infinite
	3148954	Left Front
	3148952	Left Rear
	3148954	Right Rear
	3148952	Right Front
5	8523265	Light, Indicator
6	3196068	Lens, Light
7		Knob, Infinite (4)
	9761964	Black
	9761962	White
8	8053912	Shield, Heat

Illus. No.	Part No.	DESCRIPTION
9	3196166	Screw
10	8272473	Cover, Upper
11	9762095	Brkt-Mntg, Console
12		Control, Range
	W10108100	Black
	W10108090	White
13	3196178	Screw
14	3196200	Clip, Spring
15	3196169	Screw
16	3400882	Screw
17	9762078	Brkt-Mntg, EOC
18	8273564	Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: RF264LXSQ2, RF264LXSB2
(Designer White) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

For Models: RF264LXSQ2, RF264LXSB2

(Designer White) (Black)

INSULATION

8272616 Insulation, Wrap


8272612 Insulation, Back

W10174142

DRAWER & BROILER PARTS

For Models: RF264LXSQ2, RF264LXSB2

(Designer White) (Black)




Illus. No.	Part No.	DESCRIPTION
1	W10138079	Rack, Oven (2)
2	9761031	Drawer, Storage
3	9758200	Bracket, Drawer(2)
4		Rivet, Push (2)
	3196814	White
	3196813	Black
5		Panel, Drawer Frnt
	8053339	White
	8053341	Black
6	8053334	Glide, Drawer (2)
7	3196168	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: RF264LXSQ2, RF264LXSB2
(Designer White) (Black)



Illus. No.	Part No.	DESCRIPTION
1	9762391	Trim, Top
	9761975	Black
	9761975	White
2	3196164	Screw
3	9761983	Handle, Door
	9761982	Black
	9761982	White
4	9761344	Liner, Door
5	8522414	Seal, Window
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass

Illus. No.	Part No.	DESCRIPTION
8	8272618	Insulation, Door
9	9761357	Retainer, Insul.
10	9761493	Hinge, Door (2)
11	W10075990	Glass, Outer
	W10075990	Black
	W10075980	White
12	8523171	Trim, Side
	8523171	Black Left Hand
	8523165	Black Right Hand
	8523166	White Left Hand
	8523172	White Right Hand

Illus. No.	Part No.	DESCRIPTION
13	3196160	Screw
14	8523177	Trim, Lower
	8523177	Black
	8523175	White
15	W10031790	Screw
16	W10031780	Screw
17	W10113759	Strap, Door
18	3196165	Screw
19	3195809	Bumper, Door (2)
20	3196794	Bracket, Window(2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: RF264LXSQ2, RF264LXSB2

(Designer White) (Black)

Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)		

SPLICING WIRES--25FT. LENGTH

242828	Wire, Black
	12 Ga. 150° c
242821	Wire, Blue
	14 Ga. 150°c
242822	Wire, Brown
	14 Ga. 150°c
242830	Wire, Brown
	14 Ga. 200°c
242823	Wire, Green
	14 Ga. 150°c
242824	Wire, Orange
	14 Ga. 150°c
242825	Wire, Red
	14 Ga. 150°c
242831	Wire, Red
	14 Ga. 200°c
242827	Wire, Yellow
	14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

Illus. No.	Part No.	DESCRIPTION
<u>INSULATION</u>		
	261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
	240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	4392899	Biscuit
	511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

	350930	White
	4392901	Biscuit
	285006	Superior Black
	206922	Primer (White)

PAINT, BULK (1 qt.)

	799344	White (Uncut)
	4392900	Biscuit (Uncut)

Illus. No.	Part No.	DESCRIPTION
<u>ACCESSORY PARTS</u>		
	241430	Foil, Aluminum Oven (18" x 25')
	3184478	Cleaner, Glass
	4396923	Broiler Pan Assy

ANTI-TIP KIT

	W10017440	Anti-Tip Kit
--	-----------	--------------

WIRING HARNESS PARTS

	W10114335	Harness, Wire (Main)
	W10084660	Harness, Wire Door Switch/Sensor
	9761476	Harness, Wire (Surface Unit)
	311227	Wire, Ground
	3196154	Screw
	313660	Clip, Wire Ground
	3196173	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST